



SONIC ROSE QUARTZ LED DEPUFFING PEN | 8 IN 1



Skin Scan & Personal Routine Guide



Detox Rose Quartz Spa Session



Crystal Face-Sculpting System



High-Efficiency Skin Lifting System



Precision Massage Design



SmartSonic Pulsation Technology




360° Massage Sphere



LED Decorative Light

Detox
Rose Quartz



Create your personal Skincare Routine

and Download our GESKE App



GESKE Beauty Tech GmbH
Leipziger Platz 18
10117 Berlin Germany
info@geske.com, www.geske.com



GOOD TO KNOW

TIP 01

The 360° Massage Sphere and Precision Massage Design allow you to reach every part of your face for optimal results.

TIP 02

The stone itself has a cooling effect on the skin, which can be intensified by storing the device in the fridge for around 20 minutes before each use.

TIP 03

The device switches off automatically after 30 minutes for your safety.



LED Light

Better Visibility



On/Off

Press for 1-2 Seconds



Rose Quartz

360° Massage Sphere



MASTER THE FIRST STEPS

Our SmartAppGuided™ Sonic Rose Quartz LED Depuffing Pen | 8 in 1 is a miracle creation that channels healing rose quartz and anti-aging sonic pulsations to suffuse your skin with youthful glow and vitality.



REVIVIFYING FACE & NECK LIFT

PREPARE

Apply a serum or cream of your choice on the areas you will work on. This will allow the device to glide smoothly over your skin.

POWER ON

Hold the power button for 2 seconds to turn on the SmartSonic Pulsations.

LIFT

Roll the device along your skin in an upward and outward motion. Some common areas to go over include along your jawbone starting at the chin, over the cheekbone, and across the forehead. Roll the device along the side of your neck up to the jawbone. Make sure to cover all areas of the neck.

FINISH

Turn off the device and rinse it with water to remove any leftover cosmetics. Clean your device with our Organic Device Cleanser after every use.



FOCUS AREAS

CHIN

Place the device on your chin and move it along the jawline out to the ear. Do this on both sides of the face.

CHEEKS

Glide the device from the smile lines out to the ear, covering all areas of the cheek. Do this on both sides of the face.

NOSE

Place the device next to the nose and glide it over the upper part of the cheek in the direction of the temple.

FOREHEAD

Glide the device horizontally from the center of the forehead to the temple, covering all areas of the forehead. Do this on both sides of the face.

Create your personal Skincare Routine

and Download our GESKE App



Advanced App



Video Guided



AI Powered Skin Scan



Expert Tips



Personal Guide



In App Rewards



IMPORTANT SAFETY INFORMATION. READ BEFORE USE.

Read the safety information before first use. Keep both instructions for use.

Your product at a glance

Your product is a rose quartz stick for the face. This can be used safely up to three times a day. Please do not use more often. For maximum safety and optimal results, always follow your personalized skincare routine created by the GESKE app.

Notes on Use

Before using the device for the first time, this Safety Brochure and the Quick Start Guide must be read in their entirety. Both manuals should be retained as they contain important information on safe usage as well as on technical and legal guidance. The device is a skincare product for adults, not a medical device and not a product with medical or other healing properties. The intended use also includes observing the Quick Start Guide, the warnings listed here and the personalized application recommendations from the GESKE app. The device is rechargeable and allows for easy and wireless operation. It must be fully charged before the first use. All you need is the included USB charging cable. The initial charge can take up to eight hours. The cable must dock with both magnetic contacts on the device's designated metal contact points. If the charging cable does not attach by itself, connect it to the power and wait a moment. This reactivates the magnetic effect and the contacts connect automatically. Make sure that the magnetic contacts only connect to the contact points of the device, not to other metallic surfaces.

Specifications

Materials: ABS, rose quartz, silicone | Storage Temperature: -5 – +60 °C / 23 – 140 °F | Water Protection Class: IPX7 (Protection from short-term immersion, up to 1 meter deep for 30 minutes) | Battery: Li-Ion 3.7V | Battery Capacity: 140 mAh | Maximum Charging Current: 120 mA | Charging Voltage: 5V | Charging Time: approx. 2 hours | Interface: USB | Programs: LED Decorative Light: 1 color (White), Vibration: 1 speed level

The product is not suitable for use under the following conditions:

- After laser treatment or chemical peeling
- After facial surgery, both cosmetically and medically indicated
- In case of neurodermatitis, herpes or other skin diseases

Further information on use:

- Do not use the product on irritated or injured skin or open wounds (after any kind of injury), in the case of bacterial or viral infections of the skin (either in the usage area and elsewhere)
- This product is not intended to treat medical skin conditions or diseases. If you have medical skin conditions or diseases, consult your dermatologist before using this product
- Do not use the product if it is 1) damaged or deformed, 2) discolored
- If pain and/or discomfort occurs during use, discontinue use and seek medical advice
- The eye area is very sensitive: Be extra careful in this area and avoid any contact of the product with the eyelids or the eye itself
- Only use the product as recommended in your personalized routine
- For hygiene reasons, we recommend you do not share your product with anyone else
- The product is intended for cosmetic use on the face and body. GESKE accepts no liability for harmful consequences resulting from application to other parts of the body or other improper use
- After each session, you should clean the used product with lukewarm water and our Organic Device Cleanser and then allow it to dry
- The ball of the device rotates 360° and rolls gently over the skin
- Use a moisturizing cream or serum to help the device glide over your skin. Do not exert too much pressure on the skin during the application
- You can use this product to lift the skin and to help stimulate lymph flow as well. This reduces swelling
- To achieve a lifting effect, you should glide over the skin in gentle upward movements
- You help to stimulate the lymph flow by gliding the device over the surface of the skin using slow, rhythmic strokes along the lymphatic system. It is always important to move outwards, as waste products are removed via the lymphatic system
- The device can be used with or without SmartSonic Pulsations. However, the vibrations ensure enhanced stimulation of blood circulation
- The stone can break if it falls onto hard surfaces. To prevent this, store the product safely in a box or cloth bag

Warnings

Risk of injury if used incorrectly!

Only use the product as directed in the Quick Start Guide and video instructions. If you still have questions, please contact our Customer Support at support@geske.com.

Risk of injury due to fire/ignition!

Do not extinguish the product with water. Do not throw the product into fire.

Risk of injury due to defective batteries!

Improper handling of batteries can cause an uncontrolled exothermic reaction. In such a case, dispose of the entire product immediately and properly.

Risk of injury to children!

Keep the product out of the reach of children.

Risk of injury from electric shock!

Liquid can damage the charging circuit and endanger your health. Disconnect the product from the charging cable/circuit while cleaning.

Risk of damage from magnetic fields!

Magnetic fields can affect the mechanical and electronic components such as pacemakers, for example. Do not use the product directly over a pacemaker. Contact your treating physician for more information. Do not place cards with magnetic strips (e.g. credit cards) near the product, as the product's magnets may cause damage.

Risk of damage due to changing surrounding temperatures!

Changing surrounding temperatures (e.g. after transport) may lead to the formation of condensation. In this case, do not operate the product until it has adjusted to the new surrounding temperature. Never expose your product to direct sunlight, extreme heat or boiling water. Safe use up to a surrounding temperature of 50°C (122°F).

Risk of damage from charging too long!

Disconnect the charging cable from the circuit after charging is complete. Safe charging up to a surrounding temperature of 45°C (113°F).



Information on device disposal and WEEE

This electrical appliance was first released after August 13, 2005. In accordance with the European WEEE Directive and national regulations, the electrical appliances and electronic parts included in this delivery must not be disposed of via your household waste. At the end of the product life, they must be disposed of at a municipal collection point in order to ensure environmentally friendly disposal.

Notes on batteries / rechargeable batteries

In the context of distributing batteries and rechargeable batteries, in accordance with European regulations we are obliged to inform you, the consumer, of the following: You are legally obliged to return batteries and rechargeable batteries. After use, you can return them to us, take them to a municipal collection point, or deliver them to a local dealer free of charge. Batteries and rechargeable batteries are labelled as follows:



These symbols mean that the batteries and rechargeable batteries cannot be disposed of by you, the consumer, via household waste. Batteries and rechargeable batteries containing harmful substances are labelled with one of these symbols. The symbol consists of a crossed-out wheeled bin and the chemical symbol of the heavy metal which constitutes the main pollutant. In detail, the aforementioned symbols mean:

Pb = battery contains lead, Cd = battery contains cadmium, Hg = battery contains mercury

Notes on lithium batteries/rechargeable batteries

You can recognize lithium batteries and lithium rechargeable batteries through the chemical symbol „Li“. In addition to the information provided above, we would also like to point out the following: When disposing of lithium batteries or rechargeable batteries, either by returning them to us, taking them to a municipal collection point or handing them in to local retailers or public waste disposal companies, please ensure that they are completely discharged. We also request that you cover the contact surfaces on the battery marked „+“ and „-“ with adhesive tape to avoid the risk of fire.



GESKE Beauty Tech Trade GmbH, Leipziger Platz 18 10117 Berlin hereby declares that all electronic devices conform with the relevant conditions of the applicable European Directives 2014/30/EU and 2011/65/EU.

Limitation of liability

GESKE Beauty GmbH and/or their retailers are liable for damages caused by intentional or grossly negligent behaviour of Triple A Import GmbH, a representative or vicarious agent, in accordance with legal directives. With the exception of injury to life, limb or health, and breach of essential contractual obligations (cardinal obligations), Triple A Import GmbH and/or their retailers are only liable for damages which can be attributed to intentional or grossly negligent behaviour. This also applies to indirect damages, in particular lost profits. Moreover, liability with regard to consumers due to an assumed guarantee, except in the case of intentional or grossly negligent behaviour, or where there is an injury to life, limb or health and a breach of essential contractual obligations (cardinal obligations) is limited to the typical, foreseeable damages on conclusion of the contract, and also to the level of the average damages typical for this contract. This also applies to indirect damages, in particular lost profits. With regard to companies, except in the case of injury to life, limb or health or intentional or grossly negligent behaviour by Triple A Import GmbH, and/or its retailers liability is limited to the typical, foreseeable damages on conclusion of the contract, and also to the level of the average damages typical for this contract. This also applies to indirect damages, in particular lost profits. No liability will be accepted for damages due to: Non-compliance with this manual/ Improper use/ Unauthorised alterations/ Technical modifications/Use of unapproved spare parts/Use of unapproved accessories. Claims for liability due to the German product liability legislation remain unaffected.